Model #

1154GBCHa Cascade

11-Drawer Dresser

Glazed Black Cherry finish

Assembly Instructions



IMPORTANT NOTES:

- For normal household use only. *Not* recommended to use this product in a commercial setting.
- Do not climb, sit or stand on or in this piece of furniture.
- Do not overload the drawers.
- Unload items before you move this unit.
- Before you load or move this unit, tighten all screws and supports.
- Before you begin your project, completely read the Assembly Instructions.
- Store this item: 1- in its box; 2- in a dry place; 3- in temperatures that range from 40°F to 90°F (not on a cold and possibly damp cement floor).
- Periodically inspect your furniture for any loose glue joints, screws or any other problem that might affect the stability of your furniture. Tighten or repair as needed.

WARNING

- Serious or fatal crushing injuries can occur from furniture tip-over. To help prevent tip-over:
- Place heaviest items in the bottom drawers.
- Unless specifically designed to accommodate, do not set TVs or other heavy objects on top of this product.
- Never allow children to climb or hang on drawers, doors or shelves.
- Never open more than one drawer at a time.
- Properly installing tip-over restraints may reduce but does not eliminate the risk of tip-over.

DESIGN SUBJECT TO CHANGE WITHOUT NOTICE

Congratulations!

This fine piece of furniture will make a gorgeous addition to your home. For the best results, read the Assembly Instructions before you begin your project.

CALL US FIRST! Do not return this item to the store

Service Policy: We will replace any part that is defective, missing or damaged during assembly. For a replacement part, directly contact Whittier Wood Products customer service department by phone, fax, mail or email.

Hours: Our friendly customer service staff can be reached Monday-Friday 7:00 a.m. to 5:00 p.m. (Pacific Time). You may leave a message 24 hours a day, seven days a week. **To Order:** Provide the finish and furniture model number (upper portion of this page), the part letter, production code, quantity needed, reason for replacement and your full name, address and telephone number.

Parts ship from our Eugene, Oregon factory within one or two business days from the time we receive your request. Please allow five to ten business days for delivery.

800-653-3336 • Outside the U.S. or Canada: 541-687-0213 • Fax: 541-687-2060 www.whittierwood.com • P.O. Box 2827 • Eugene, Oregon 97402, U.S.A.



P.O. Box 2827 Eugene, OR 97402 USA

Production C	Code:
--------------	-------

Please identify the parts and check that quantities received match those on this list. If you need to replace a part, refer to the following letter(s) and part name.

Part	Description	Quantity
A	Top Assembly (attached)	
Ва	Case	
С	Left/Right Top Drawer Box (inserted)	. 2
D	Left/Right Middle Drawer Box (inserted)	. 2
E	Left Secret Storage Drawer Box (inserted)	· 1
F	Right Secret Storage Drawer Box (inserted)	1
G	Upper Middle Drawer Box (inserted)	3
Н	Large Bottom Drawer Box (inserted)	2
1	Small Top Drawer Face (installed)	
J	Left/Right Upper Middle Drawer Face (installed)	2
к	Center Upper Middle Drawer Face (installed)	
L	Large Upper Drawer Face (installed)	2
M	Large Bottom Drawer Face (installed)	··· 2
N	Tray (inserted)	1
0	Assembled Foot (attached)	1
Р	Small Pull (attached)	12
Q	#8 x 1-1/2" Machine Screw (installed)	24
R	Large Pull (attached)	a 4


1154GBCHa Cascade 11-Drawer Dresser

Parts List


Part	Description		Quantity
S	#8 x 1-1/4" Machine Screw (installed)		8
Т	Drawer Slides (pre-installed sets)	00 00 00	11
U	#6 x 1/2" Philtruss Screw (inserted)		66
V	#6 x 3/4" Philtruss Screw (inserted)	Common Common	66
W	Hinged Drawer Stop (attached)		2
Х	#6 x 5/8" Undercut Screw (inserted)	(juuu>	4
Y	Hex Bumper (attached)	\bigcirc	2
Z	M4 x 10mm Insert Nut (inserted)		8
ZA	1/4" x 20mm Insert Nut (inserted)		5
ZB	Adjustable Glide (installed)		5
ZC	#8 x 7/8" Lo-Profile Screw (inserted)	aaaaaaa	54
ZD	#8 x 1-1/8" Lo-Profile Screw (inserted)		4
ZE	#8 x 1-1/4" Pan Head Screw (inserted)	(#)0000000000000000000000000000000	40
ZG	#8 x 1-5/8" Black Screw (inserted)		11
ZH	#8 x 2" Black Screw (inserted)		2
ZI	Pad Strip (attached)		1
ZJ	Small Velvet (attached)		1
ZK	Large Velvet (attached)		1
ZL	#8 x 1-3/8" Lo-Profile Screw (inserted)	accecececece ()	10
TR	Furniture Tipping Restraint		2 sets

Tool Required: Phillips Screwdriver


 Open the Right Secret Storage Drawer (F) and remove the foam packaging that contains the Tray (N). Recycle the packaging and return the Tray (N) to the drawer. See Figure 1 and 1a.



2. There are secret storage areas in the top two middle drawers. To access either of these storage areas, open the Upper Middle Drawer (G). Reach in until you find the Hinged Drawer Stop (W) that is attached to the bottom right sides of the Left Secret Storage Drawer (E) or the Right Secret Storage Drawer (F). Pull the Hinged Drawer Stop (W) forward and then pull the drawer; Left Secret Storage Drawer (E) or the Right Secret Storage Drawer (F) out far enough so you can access the concealed storage space. To close the drawer, just push it shut. See Figure 2.



3. Place the dresser at its final destination. Rotate the Adjustable Glides (ZB) on the bottoms of the legs and Assembled Foot (O) until the unit is level. See Figure 3.



4. Tipping restraint: Locate two studs in the wall behind the unit. Attach a Clip (T1) to one wall stud with two #8 x 2" Black Screws (T3). See Figure 4a. Attach a second clip to the unit with two #8 x 1" Pan Head Screws (T4). See Figure 4b. Connect the two clips with the Nylon Restraint Strap (T2). Pull the Nylon Restraint Strap (T2) tight so there is no slack. See Figures 4c and 4d. Repeat this procedure to attach the second tipping restraint. If you cannot locate two studs, purchase the proper wall attachment hardware for your type of wall and secure the unit.

