
# **2901AFGAC** Kingswood **Plank Table** 42"x 66"-96"

(Glazed Antique Cherry Finish)

Assembly Instructions



### **Congratulations!**

This fine piece of furniture will make a handsome addition to your home. For the best results, start by reading the Assembly Instructions before you begin your project.

#### For normal household use only. **NOT** recommended for commercial use.

Unload items from this unit prior to moving. Before loading or moving this unit, check all screws and supports for tightness.

Do not sit, stand or climb on this piece of furniture.

#### **DESIGN SUBJECT TO CHANGE WITHOUT NOTICE.**

# **CALL US FIRST!** DO NOT RETURN ITEM TO STORE

Service Policy: We will replace parts which are defective, missing or damaged. Please contact Whittier Wood Products customer service department directly (by phone, fax, mail or E-mail) for replacement parts.

Hours: Our friendly customer service staff can be reached Monday-Friday 7:00 a.m. to 5:00 p.m. (Pacific Time). A message can be left 24 hours a day, 7 days a week.

**To Order:** Provide the complete furniture model number, part letter, production code, quantity needed, reason for replacement and your full name and address along with a telephone number in case we need to contact you.

Parts ship from our Eugene, Oregon factory within 1 or 2 business days from the time we receive the request. Please allow 5-10 business days for delivery.

## 800-653-3336

Outside U.S. or Canada: 541-687-0213 Fax: 541-687-2060 • www.whittierwood.com Mail: P.O. Box 2827 • Eugene, Oregon 97402, U.S.A

## **IMPORTANT NOTES:**

- Store the item: 1) in the box; 2) in a dry place; 3) in temperatures ranging from 40° to 90°. (Not on a cold, possibly damp, cement floor.)
- Inspect your furniture periodically for any loose glue joints or screws, or any other problem which may be affecting the stability of your furniture. Tighten or repair as needed.
- This Assembly requires two people.




P.O. Box 2827 Eugene, OR 97402 USA

VN

## 2901AFGAC Kingswood Plank Table 42"x 66"- 96" - Parts List

Please identify the parts and check that quantities received match those on this list. If you need to replace a part, refer to the following letter and model name.



Place Top Assembly (A) upside-down on a clean, protected surface. Position Legs (B) on Top Assembly (A) outside of and against the corners of the aprons. Insert 3/8" x 2<sup>1</sup>/<sub>2</sub>" Hex Bolt (N) through Washer (O) and Bracket, and screw into Leg (B). Tighten bolts. See Figure 1a. Turn your table upright.

Retighten bolts (N) after first week of use.